



4444 OCEAN HEIGHTS COURT • SEASIDE • CALIFORNIA 93955 • (831) 393-0588 • (831) 393-0578 FAX
EMAIL: MDC@MDCSTIRRUPS.COM / FACEBOOK: MDC STIRRUPS / INSTAGRAM @MDC_STIRRUPS

MDC 4 PIN ALUMINUM PAD INSTALLATION INSTRUCTIONS

To remove or replace the MDC low-profile, high traction aluminum treads, use a 3mm hex head wrench as provided with all optional traditional width treads using our 4 pressure pin design. Your treads are also set in place with a silicone adhesive. You will need to hammer the treads away from the stirrup using a plastic or rubber hammer as the silicone has produced a tight seal. If you use a metal hammer, you must protect the soft aluminum material with a towel. Strike the treads firmly to release the silicone seal. If the tread remains in place, strike the tread with more force.

We want your treads to be secure and tight. Remove the tread and apply a bead of waterproof, 100% outdoor silicone to the underside of the pads to the left and right of the four rails where the four pressure pins attach. Put the treads back in place, and let the silicone dry. Use a drop of blue thread locker on the four pins so they remain secure. This should insure a secure fit with no tread movement. You may need to use a rubber or plastic hammer to tap your stirrups into place.

A recommended silicone product available in the USA is GE, Premium Waterproof 100% Clear Silicone II.

ALWAYS CHECK THE TIGHTNESS OF THE PINS FOR A SECURE ATTACHMENT FOR YOUR SAFETY.

IT IS A GOOD HORSEMAN WHO CHECKS THEIR TACK AND THE CONDITION OF THEIR HORSE PRIOR TO EVERY RIDE.



NEWER MODELS USE THE SMALL FOUR PIN ATTACHMENT